

Shown on manual transmission 716.6

- 1 Pedal assembly
- 2 Circlip
- 3 Washer
- 4 Brake pedal
- 5 Bushes
- 6 Pedal rubber



P29.10-2032-12

 	Remove/install		
1	Remove foot controls (1)	Transmission 716.6 without Sequentronic automated manual transmission (ASG) Transmission 722.6 Transmission 716.6 with Sequentronic automated manual transmission (ASG) code 424	AR29.10-P-0300T AR29.10-P-0300TA
2	Remove circlip (2).		
3	Remove washer (3)		
4	Remove brake pedal (4)		
	Checking		
5	Check bushing (5) for signs of wear and replace if necessary	 Installation: Apply light coating of grease (5) to inside diameter. Long-life grease	*BR00.45-Z-1001-06A
6	Check rubber pad (6) for signs of wear and replace if necessary		
7	Install in the reverse order		

Repair materials

Number	Designation	Order number
BR00.45-Z-1001-06A	Long-life grease	A 000 989 63 51 11