


AH05.20-N-0100-01A	Camshaft code number and assignment		
--------------------	-------------------------------------	--	--

Engine 111.948/978, 112, 113
Engine 111
Engine 120
Engine 601, 602, 603

Engine 111


i The camshaft key figure is located on the 2nd camshaft bearing (arrow).



P05.20-0239-01

Engine 112, 113


i The camshaft code number is located at the flange for the camshaft sprockets (arrow).



P05.20-0304-01

Engine 120


The camshaft key figures are to be read off the bearing points 3 and 10 on the right cylinder head and bearing point 17 and 24 on the left cylinder head (behind bearing caps) (arrows) and stamped onto the camshaft flange with a color (arrows).



P05.20-0358-01

Engine 601, 602, 603

The key figure is stamped onto the flange next to the top dead center notch (arrow).



P05.20-0341-01